

General instructions for cleaning and care

no.56 Laminate floorings (smooth)





















cleaning system without treatment
end of construction

object _____
address _____
room classification _____

date _____
customer _____
representative _____

work process: select one work stage from each number

↓	cleaning method	recommendations * chemical products	dosage	recommendations pad / brush / mop / cloth	recommendations machine / tool	comments
1	 dusting  damp mopping			Masslinn S Microsol cloth S Synthetic fur	Balit with pad sole Balit with velcro	
1	 dry vacuum cleaning			V S Dust roller nozzle V Combi-nozzle	Twinvac Monovac Portavac	if needed
cleaning without maintenance care product (if coating follows)						
2	 spray cleaning full spray	Antiwax forte classic	0.5 - 1%	● Pad red P ● HS-Polish pad beige P ○ HS-Polish pad white	Monomatic DS Spray unit	after polishing  
2	 wet mopping single step	Ecofloor Alcosal V Reshine	0.5 - 1% 1 - 2% 1 - 2%	V S Microbrush-mop Microsmooth-mop V S Silkysmooth-mop	Wetbox system Socar / Drewell Wetcar / Drewell	 
2	 scrubber drying single step	Ecofloor V Reshine V Antiwax forte classic	0.5 - 1% 1 - 2% 0.5 - 1%	● Microsol fibre pad ● Pad red V ● Melamine pad	Duo- / Discomatic Sprinter / Drivematic	
cleaning with maintenance care (first protective treatment with same product as in maintenance cleaning)						
3	 wet mopping single step	Redur Remop C Brill	3 - 4% 2 - 3% 3 - 5%	V S Microbrush-mop Microsmooth-mop V S Silkysmooth-mop	Wetbox system Socar / Drewell Wetcar / Drewell	Brill should be used with Silkysmooth mop only.  
3	 scrubber drying single step	Redur Remop C Brill	3 - 4% 2 - 3% 3 - 5%	● Microsol fibre pad ● Pad red ● Melamine pad	Duo- / Discomatic Sprinter / Drivematic	
3	 spray cleaning full spray	Polyspray C Waxspray C Polish	100% 100% 30%	● Pad red P ● HS-Polish pad beige P ○ HS-Polish pad white	Monomatic DS Spray unit	after polishing 

* basic treatment / structure: B: coated / C: waxed / D: oiled / E: sealed / F: untreated / G: maintenance care product / H: Disinfection / P: polishing / S: structured / V: heavily soiled

important: When spray cleaning, you should change your pad often.

General instructions for cleaning and care

no. 56 Laminate floorings (smooth)






























maintenance cleaning

object _____
 address _____
 room classification _____

date _____
 customer _____
 representative _____

work process: select one work stage from each number

↓	cleaning method	freq uenc	* recommendations chemical products	dosage	* recommendations pad / brush / mop / cloth	recommendations machine / tool	comments	
1	 dusting damp mopping	<input type="checkbox"/>			Masslinn S Microsol cloth S Synthetic fur	Balit with pad sole Balit with velcro		
2	 chewing gum removal	<input type="checkbox"/>	Karpfrost Karpotek	100% 100%			if needed	
cleaning without maintenance								
3	 wet mopping single step	<input type="checkbox"/>	Ecofloor Reshine Alcosal	0.5 - 1% 1 - 2% 1 - 2%	V S Microbrush-mop Microsmooth-mop Silkysmooth-mop	Wetbox system Wetcar / Drewell Socar / Drewell		 
3	 spray mopping (wet mopping)	<input type="checkbox"/>	Ecofloor Reshine Alcosal	0.5 - 1% 1 - 2% 1 - 2%	V Micro nonwoven-1- Micro woven-1- Silkysmooth-1-	Variwet handle Balit with velcro Micro velcro sole		 
3	 scrubber drying single step	<input type="checkbox"/>	Ecofloor Reshine Libero	0.5 - 1% 1 - 2% 0.5 - 3%	V  Microsol fibre pad  Pad red  Melamine pad	Duo- / Discomatic Sprinter / Drivematic		
cleaning with maintenance								
3	 wet mopping single step	<input type="checkbox"/>	Redur Remop Brill	1 - 4% 1 - 2% 1 - 2%	V S Microbrush-mop Microsmooth-mop Silkysmooth-mop	Wetbox system Wetcar / Drewell Socar / Drewell	Brill should be used with Silkysmooth mop only.	 
3	 scrubber drying single step	<input type="checkbox"/>	Redur Remop Brill	1 - 4% 1 - 2% 1 - 2%	V  Microsol fibre pad  Pad red  Melamine pad	Duo- / Discomatic Sprinter / Drivematic		
3	 spray cleaning partial / full spray	<input type="checkbox"/>	Polyspray C Waxspray C Polish	100% 100% 30%	P  Pad red  HS-Polish pad beige P  HS-Polish pad white	Monomatic DS Spray unit	after polishing	

* basic treatment / structure: B: coated / C: waxed / D: oiled / E: sealed / F: untreated / G: maintenance care product / H: Disinfection / P: polishing / S: structured / V: heavily soiled

important: When spray cleaning, you should change your pad often.

General instructions for cleaning and care

no. 56 Laminate floorings (smooth)



















interim cleaning

object _____
 address _____
 room classification _____

date _____
 customer _____
 representative _____

work process: select one work stage from each number

↓	cleaning method	freq uenc	recommendations * chemical products	dosage	recommendations pad / brush / mop / cloth	recommendations machine / tool	comments
1	 dusting damp mopping	<input type="checkbox"/>			Masslinn S Microsol cloth S Synthetic fur	Balit with pad sole Balit with velcro	
1	 dry vacuum cleaning	<input type="checkbox"/>			V S Dust roller nozzle V Combi-nozzle	Monovac Portavac Twinvac	if needed
cleaning without maintenance							
2	 wet mopping single step	<input type="checkbox"/>	Reshine G Antiwax forte C Antiwax forte classic	2 - 5% 2 - 5% 2 - 5%	V S Microsmooth-mop Microbrush-mop Silkysmooth-mop	Wetbox system Wetcar / Drewell Socar / Drewell	 
2	 scrubber drying single step	<input type="checkbox"/>	Reshine G Antiwax forte C Antiwax forte classic	2 - 5% 2 - 5% 2 - 5%	V S  Microsol fibre pad  Pad red V  Melamine pad	Duo- / Discomatic Sprinter / Drivematic	 
cleaning with maintenance							
2	 spray cleaning full spray	<input type="checkbox"/>	Polyspray C Waxspray C Polish	100% 100% 30%	 Pad red P  HS-Polish pad beige P  HS-Polish pad white	Monomatic DS Spray unit	after polishing 

* basic treatment / structure: B: coated / C: waxed / D: oiled / E: sealed / F: untreated / G: maintenance care product / H: Disinfection / P: polishing / S: structured / V: heavily soiled

important: When spray cleaning, you should change your pad often.
 For initial cleaning after interim cleaning, see "initial cleaning".

General instructions for cleaning and care




































no.56 Laminate floorings (smooth)



basic cleaning

object _____ date _____
 address _____ customer _____
 room classification _____ representative _____

work process: select one work stage from each number

↓	cleaning method	freq uenc	recommendations * chemical products	dosage	recommendations pad / brush / mop / cloth	recommendations machine / tool	comments
1	 dry vacuum cleaning	<input type="checkbox"/>			V S Dust roller nozzle V Combi-nozzle	Twinvac Portovac Monovac	if needed
2	 dusting damp mopping	<input type="checkbox"/>			S Masslinn S Microsol cloth S Synthetic fur	Balit with pad sole Balit with velcro	
3	 chewing gum removal	<input type="checkbox"/>	Karpotek Karpfrost	100% 100%			if needed 
cleaning without maintenance							
4	 spray cleaning full spray	<input type="checkbox"/>	G Antiwax forte C Antiwax forte classic	30 - 50% 30 - 50%	 Microsol fibre pad  Pad red C  Pad blue	Monomatic DS Spray unit	
4	 wet scrubbing and wet vacuuming	<input type="checkbox"/>	Antiwax forte C Antiwax forte classic C Relino	2 - 5% 2 - 5% 2 - 5%	 Microsol fibre pad  Pad red C  Pad blue	Monomatic I / LS Watertank Twinvac / Duovac	  
4	 scrubber drying single step	<input type="checkbox"/>	Antiwax forte C Antiwax forte classic C Relino	2 - 5% 2 - 5% 2 - 5%	 Microsol fibre pad  Pad red C  Pad blue	Duo- / Discomatic Sprinter / Drivematic	large areas   
5	 rinsing	<input type="checkbox"/>	Klares Wasser	100%	 Microsol fibre pad  Pad red	Monomatic I / LS Watertank Twinvac / Duovac	  
5	 rinsing	<input type="checkbox"/>	Klares Wasser	100%	 Microsol fibre pad  Pad red	Duo- / Discomatic Sprinter / Drivematic	large areas   

* basic treatment / structure: B: coated / C: waxed / D: oiled / E: sealed / F: untreated / G: maintenance care product / H: Disinfection / P: polishing / S: structured / V: heavily soiled

important: change pad often.

Use a coin or a key to do a scratch test, to check if all the protective coating has been removed.

When white abrasion occurs, carry out a full clean to remove all the protective coating.

General instructions for cleaning and care

no. 56 Laminate floorings (smooth)















protective treatment

object _____
 address _____
 room classification _____

date _____
 customer _____
 representative _____

work process: select one work stage from each number

cleaning method	recommendations * chemical products	dosage	recommendations pad / brush / mop / cloth	recommendations machine / tool	comments
1  dusting  damp mopping			Masslinn 2000 S Microsol cloth S Synthetic fur	Balit with pad sole Balit with velcro	
coating					
2  waxing	Polish	100%	Cover for Florfix Florfix-mop	Florfix Balit with velcro	1 - 3 thin layers  
3  dusting  damp mopping			Masslinn	Balit with pad sole Balit with velcro	if needed
buffing wax treatment (only if necessary)					
4  polishing, vacuum  polishing			C  HS-Polish pad beige C  HS-Polish pad white	Monomatic HS Suction ring Suction unit	after polishing 

* basic treatment / structure: B: coated / C: waxed / D: oiled / E: sealed / F: untreated / G: maintenance care product / H: Disinfection / P: polishing / S: structured / V: heavily soiled

important: if needed

before protective treatment: the floor must be perfectly stripped, thoroughly rinsed and completely dry!
 Let dry protection treatment completely between the layers and before use.
 Process treatment of prote
 For initial cleaning with maintenance cleaner after protective treatment, see "initial cleaning".

General instructions for cleaning and care

no. 56 Laminate floorings (smooth)



Information about the flooring



Wetrok AG cannot accept any liability for damages due to improper use.
For security information, see the safety data sheet at www.wetrok.com.
Wear the required personal protective equipment (PPE): e.g. protective gloves, safety goggles, work shoes.
Follow the information and remarks on the label, product data sheet and material safety data sheet.
The product data sheet describes the product and gives information about its application, storage. See www.wetrok.com.
The recommended colours of pad and brushes consist to the actual wWetrok product range.
Follow the special cleaning and care instructions of the floor manufacturer.
The cleaning and care instructions are recommendations and suggestions and apply to floorings in object quality.



Strong alkalines can destroy or discolour wood coverings. Use a special basic linoleum cleaner!

Laminated coverings are sensitive to abrasive pads and brushes.

Water can penetrate into the laminated covering through the joints.

Distinguishing feature: appearance of wood, bright sound when tapped.

Allow it to dry completely before applying a protective treatment! Allow longer drying times than for non-porous coverings such as PVC.



Humidity variations cause wood to shrink (dry out) or swell (exposure to moisture) and, possibly, warp (moisture).

Distinguishing feature: appearance of wood, dull sound when tapped.



Remove loose dirt before every cleaning, damp mop smooth floors and vacuum structured floors.

Cleaning agents and surface treatments may alter the appearance and properties of a floor's surface.

Test on an inconspicuous spot to find which product is suitable for your requirements.

Test beforehand on an inconspicuous spot to see if the cleaning agent or surface treatment damages the floor.

Dirt-trapping zones, incl. dirt-trapping mats (Wetrok Gardamat) in the entrance, at least 7m long, greatly reduce the amount of dirt tracked into the building.

If you have any questions, please don't hesitate to contact us.

For training courses, contact the Wetrok Academy, tel. +41 (0)43 255 51 43 or academy@wetrok.ch.

Wetrok AG Steinackerstrasse 62, CH-8302 Kloten, telephone +41 (0)43 255 51 51, info@wetrok.ch, www.wetrok.com.