

General instructions for cleaning and care

no.34 Synthetic resin treated industrial flooring (smooth)
















cleaning system with treatment
end of construction

object _____
address _____
room classification _____

date _____
customer _____
representative _____

work process: select one work stage from each number

↓	cleaning method	recommendations * chemical products	dosage	* recommendations pad / brush / mop / cloth	recommendations machine / tool	comments
1	 dusting damp mopping			S Masslinn V Microsol cloth Multi squeegee	Balit with pad sole	
1	 dry vacuum cleaning			V S Dust roller nozzle V Combi-nozzle	Twinvac Monovac Portovac	if needed
cleaning without maintenance care product (if coating follows)						
2	 wet mopping single step	V Ecofloor V Reshine V Antiwax forte classic	0.5 - 1% 1 - 2% 0.5 - 1%	Silkysmooth-mop Microsmooth-mop Microbrush-mop	Wetbox system Socar / Drewell Wetcar / Drewell	
2	 scrubber drying single step	V Ecofloor V Reshine V Antiwax forte classic	0.5 - 1% 1 - 2% 0.5 - 1%	● Pad red ● Pad blue ● Microsol fibre pad	Duo- / Discomatic Sprinter / Drivematic	
2	 wet scrubbing and wet vacuuming	V Reshine V Antiwax forte V Rewit 2000	1 - 2% 0.5 - 1% 0.5 - 1%	● Pad red ● Pad blue	Monomatic I / LS Watertank Twinvac / Duovac	heavily soiled  
cleaning with maintenance care (first protective treatment with same product as in maintenance cleaning)						
3	 wet mopping single step	Redur Remop	3 - 4% 2 - 3%	Silkysmooth-mop Microsmooth-mop Microbrush-mop	Wetbox system Socar / Drewell Wetcar / Drewell	
3	 scrubber drying single step	Redur Remop	3 - 4% 2 - 3%	● Pad red ● Microsol fibre pad	Duo- / Discomatic Sprinter / Drivematic	
3	 spray cleaning full spray	Polyspray Elfspray	100% 100%	● Pad red P ● HS-Polish pad beige P ○ HS-Polish pad white	Monomatic DS Spray unit	after polishing 

* basic treatment / structure: B: coated / C: waxed / D: oiled / E: sealed / F: untreated / G: maintenance care product / H: Disinfection / P: polishing / S: structured / V: heavily soiled

important: When spray cleaning, you should change your pad often.

General instructions for cleaning and care

no.34 Synthetic resin treated industrial flooring (smooth)



maintenance cleaning

object _____

date _____

























address _____

customer _____

work process: select one work stage from each number

room classification _____

representative _____

↓	cleaning method	freq uenc	recommendations * chemical products	dosage	recommendations * pad / brush / mop / cloth	recommendations machine / tool	comments
1	 dusting damp mopping	<input type="checkbox"/>			Masslinn S Microsol cloth S Synthetic fur	Balit with pad sole Balit with velcro	
1	 dry vacuum cleaning	<input type="checkbox"/>			V S Dust roller nozzle V Combi-nozzle	Monovac Twinvac Portovac	if needed
cleaning without maintenance							
2	 wet mopping single step	<input type="checkbox"/>	Ecofloor Reshine Alcosal	0.5 - 1% 1 - 2% 1 - 2%	V S Microbrush-mop Microsmooth-mop Silkysmooth-mop	Wetbox system Wetcar / Drewell Socar / Drewell	
2	 spray mopping (wet mopping)	<input type="checkbox"/>	Ecofloor Reshine Alcosal	0.5 - 1% 1 - 2% 1 - 2%	V Micro nonwoven-1- Micro woven-1- Silkysmooth-1-	Variwet handle Balit with velcro Micro velcro sole	
2	 scrubber drying single step	<input type="checkbox"/>	Ecofloor Reshine Libero	0.5 - 1% 1 - 2% 0.5 - 3%	V  Pad red  Melamine pad  Microsol fibre pad	Duo- / Discomatic Sprinter / Drivematic	
cleaning with maintenance							
2	 wet mopping single step	<input type="checkbox"/>	Redur Remop	1 - 4% 1 - 2%	V S Microbrush-mop Microsmooth-mop Silkysmooth-mop	Wetbox system Wetcar / Drewell Socar / Drewell	
2	 scrubber drying single step	<input type="checkbox"/>	Redur Remop	1 - 4% 1 - 2%	V  Pad red  Melamine pad  Microsol fibre pad	Duo- / Discomatic Sprinter / Drivematic	
2	 spray cleaning partial / full spray	<input type="checkbox"/>	Polyspray Elfspray Stoner	100% 100% 50%	 Pad red P  HS-Polish pad beige P  HS-Polish pad white	Monomatic DS Spray unit	after polishing 
2	 US spray cleaning partial / full spray	<input type="checkbox"/>	B US Restorer	100%	 US-Polish pad beige	Monomatic US Spray unit	after polishing 

* basic treatment / structure: B: coated / C: waxed / D: oiled / E: sealed / F: untreated / G: maintenance care product / H: Disinfection / P: polishing / S: structured / V: heavily soiled

important: When spray cleaning, you should change your pad often.

General instructions for cleaning and care

no. 34 Synthetic resin treated industrial flooring (smooth)



interim cleaning

object _____

date _____




















address _____

customer _____

work process: select one work stage from each number

room classification _____

representative _____

↓	cleaning method	freq uenc	recommendations * chemical products	dosage	* recommendations pad / brush / mop / cloth	recommendations machine / tool	comments
1	 dusting damp mopping	<input type="checkbox"/>			Masslinn S Microsol cloth S Synthetic fur	Balit with pad sole Balit with velcro	
1	 dry vacuum cleaning	<input type="checkbox"/>			V S Dust roller nozzle V Combi-nozzle	Monovac Portavac Twinvac	if needed
cleaning without maintenance							
2	 wet mopping two-step	<input type="checkbox"/>	Reshine Polex Antiwax forte classic	2 - 5% 2 - 4% 2 - 5%	V S Microsmooth-mop Silkysmooth-mop	Socar / Drewell Wetcar / Drewell	 
2	 scrubber drying two-step	<input type="checkbox"/>	Reshine Polex Antiwax forte classic	2 - 5% 2 - 4% 2 - 5%	V  Pad red  Pad blue  Microsol fibre pad	Duo- / Discomatic Sprinter / Drivematic	 
cleaning with maintenance							
2	 spray cleaning full spray	<input type="checkbox"/>	Polyspray Elfspray Stoner	100% 100% 50%	 Pad red P  HS-Polish pad beige P  HS-Polish pad white	Monomatic DS Spray unit	after polishing 
2	 US spray cleaning full spray	<input type="checkbox"/>	B US Restorer	100%	 US-Polish pad beige	Monomatic US Spray unit	after polishing 

* basic treatment / structure: B: coated / C: waxed / D: oiled / E: sealed / F: untreated / G: maintenance care product / H: Disinfection / P: polishing / S: structured / V: heavily soiled

important: When spray cleaning, you should change your pad often.
For initial cleaning after interim cleaning, see "initial cleaning".

General instructions for cleaning and care

no.34 Synthetic resin treated industrial flooring (smooth)



basic cleaning

object _____

date _____


































address _____

customer _____

work process: select one work stage from each number

room classification _____

representative _____

cleaning method	freq uenc	recommendations * chemical products	dosage	recommendations pad / brush / mop / cloth *	recommendations machine / tool	comments
1  dry vacuum cleaning	<input type="checkbox"/>			V S Dust roller nozzle V Combi-nozzle	Monovac Portavac Twinvac	if needed
2  dusting damp mopping	<input type="checkbox"/>			S Masslinn S Microsol cloth S Synthetic fur	Balit with pad sole Balit with velcro	
3  chewing gum removal	<input type="checkbox"/>	Karpfrost Karpotek	100% 100%			if needed 
cleaning without maintenance						
4  wet scrubbing and wet vacuuming	<input type="checkbox"/>	Rewit 2000 Antiwax forte classic B Relino	10 - 20% 30 - 50% 20 - 50%	B  Pad green  Pad blue  Microsol fibre pad	Monomatic I / LS Watertank Twinvac / Duovac	  
4  scrubber drying two-step	<input type="checkbox"/>	Rewit 2000 Antiwax forte classic B Relino	10 - 20% 30 - 50% 20 - 50%	B  Pad green  Pad blue  Microsol fibre pad	Duo- / Discomatic Sprinter / Drivematic	large areas   
4  spray cleaning full spray	<input type="checkbox"/>	Antiwax forte classic	30 - 50%	B  Pad green  Pad blue  Microsol fibre pad	Monomatic I / LS Spray unit	
5  rinsing	<input type="checkbox"/>		0 100%	 Pad blue  Microsol fibre pad	Monomatic Watertank Twinvac / Duovac	 
5  rinsing	<input type="checkbox"/>		0 100%	 Pad blue  Microsol fibre pad	Duo- / Discomatic Sprinter / Drivematic	large areas  

* basic treatment / structure: B: coated / C: waxed / D: oiled / E: sealed / F: untreated / G: maintenance care product / H: Disinfection / P: polishing / S: structured / V: heavily soiled

important: For initial cleaning after basic cleaning, see "initial cleaning".

General instructions for cleaning and care

no. 34 Synthetic resin treated industrial flooring (smooth)



protective treatment

object _____

date _____






address _____

customer _____

work process: select one work stage from each number

room classification _____

representative _____

cleaning method		recommendations * chemical products	dosage	recommendations * pad / brush / mop / cloth	recommendations machine / tool	comments
1	 dry vacuum cleaning			V S V Dust roller nozzle Combi-nozzle	Monovac Portavac Twinvac	if needed
2	 dusting damp mopping			S S Masslinn Microsol cloth Synthetic fur	Balit with pad sole Balit with velcro	
coating						
3	 coating	Mepol H Mepol HM Stoner	100% 100% 100%	Cover for Florfix Florfix-mop	Florfix Balit with velcro	1 - 3 thin layers  

* basic treatment / structure: B: coated / C: waxed / D: oiled / E: sealed / F: untreated / G: maintenance care product / H: Disinfection / P: polishing / S: structured / V: heavily soiled

important: before protective treatment: the floor must be perfectly stripped, thoroughly rinsed and completely dry!
do not coat impregnated floors.
Let dry protection treatment completely between the layers and before use.
Process treatment of protection: see description of method.
For initial cleaning with maintenance cleaner after protective treatment, see "initial cleaning".

General instructions for cleaning and care

no. 34 Synthetic resin treated industrial flooring (smooth)



Information about the flooring



Wetrok AG cannot accept any liability for damages due to improper use.
For security information, see the safety data sheet at www.wetrok.com.
Wear the required personal protective equipment (PPE): e.g. protective gloves, safety goggles, work shoes.
Follow the information and remarks on the label, product data sheet and material safety data sheet.
The product data sheet describes the product and gives information about its application, storage. See www.wetrok.com.
The recommended colours of pad and brushes consist to the actual wWetrok product range.
Follow the special cleaning and care instructions of the floor manufacturer.
The cleaning and care instructions are recommendations and suggestions and apply to floorings in object quality.



Synthetic resin coverings are sensitive to organic solvents such as acetone.

Do not use solvent-based wax. Danger of slipping!
Only coat smooth, heavily used surfaces.
There must be no coating in the open air and in wet rooms. Danger of slipping!

Synthetic resin coverings consist of epoxy, polyurethane, polyester or acrylic resins, fillers and oxides.
Industrial coverings treated with synthetic resins are non-porous, pressure-resistant, mechanically loaded floor coverings with a mat or a gloss surface.
Industrial coverings treated with synthetic resins are cast or ground without joints or with expansion joints.



Remove loose dirt before every cleaning, damp mop smooth floors and vacuum structured floors.
Cleaning agents and surface treatments may alter the appearance and properties of a floor's surface.
Test on an inconspicuous spot to find which product is suitable for your requirements.
Test beforehand on an inconspicuous spot to see if the cleaning agent or surface treatment damages the floor.
Dirt-trapping zones, incl. dirt-trapping mats (Wetrok Gardamat) in the entrance, at least 7m long, greatly reduce the amount of dirt tracked into the building.

If you have any questions, please don't hesitate to contact us.
For training courses, contact the Wetrok Academy, tel. +41 (0)43 255 51 43 or academy@wetrok.ch.

Wetrok AG Steinackerstrasse 62, CH-8302 Kloten, telephone +41 (0)43 255 51 51, info@wetrok.ch, www.wetrok.com.