

General instructions for cleaning and care

no.36 Synthetic resin treated industrial flooring (conductive/antistatic)
















cleaning system without treatment
end of construction

object _____
address _____
room classification _____

date _____
customer _____
representative _____

work process: select one work stage from each number

cleaning method	* recommendations chemical products	dosage	* recommendations pad / brush / mop / cloth	recommendations machine / tool	comments
1  dry vacuum cleaning <input type="checkbox"/>			V S Dust roller nozzle V Combi-nozzle	Twinvac Monovac	Do not use magnetic tools and machines in the
1  dusting damp mopping <input type="checkbox"/>			S Masslinn 2000 Microsol cloth	Balit with pad sole	
cleaning without maintenance care product (if coating follows)					
2  wet mopping single step <input type="checkbox"/>	Ecofloor Libero V Antiwax forte classic	0.5 - 1% 0.5 - 3% 0.5 - 1%	Silkysmooth-mop Microsmooth-mop Microbrush-mop	Wetbox system Socar / Drewell Wetcar / Drewell	
2  scrubber drying single step <input type="checkbox"/>	Ecofloor Libero V Antiwax forte classic	0.5 - 1% 0.5 - 3% 0.5 - 1%	● Pad red V ● Pad blue ● Microsol fibre pad	Duo- / Discomatic Sprinter / Drivematic	
2  wet scrubbing and wet vacuuming <input type="checkbox"/>	Antiwax forte classic Rewit 2000	0.5 - 1% 0.5 - 1%	● Pad red V ● Pad blue	Monomatic I / LS Watertank Twinvac / Duovac	heavily soiled  
cleaning with maintenance care (first protective treatment with same product as in maintenance cleaning)					
3  wet mopping single step <input type="checkbox"/>	Redur Remop	3 - 4% 2 - 3%	Silkysmooth-mop Microsmooth-mop Microbrush-mop	Wetbox system Socar / Drewell Wetcar / Drewell	
3  scrubber drying single step <input type="checkbox"/>	Redur Remop	3 - 4% 2 - 3%	● Pad red ● Microsol fibre pad	Duo- / Discomatic Sprinter / Drivematic	
3  spray cleaning full spray <input type="checkbox"/>	Polyspray	100%	● Pad red P ● HS-Polish pad beige P ○ HS-Polish pad white	Monomatic DS Spray unit	after polishing 

* basic treatment / structure: B: coated / C: waxed / D: oiled / E: sealed / F: untreated / G: maintenance care product / H: Disinfection / P: polishing / S: structured / V: heavily soiled

important: Do not use magnetic tools and machines in the MRI and server room.
When spray cleaning, you should change your pad often.

General instructions for cleaning and care

no.36 Synthetic resin treated industrial flooring (conductive/antistatic)



maintenance cleaning

object _____

date _____













address _____

customer _____

work process: select one work stage from each number

room classification _____

representative _____

↓	cleaning method	freq uenc	recommendations * chemical products	dosage	recommendations * pad / brush / mop / cloth	recommendations machine / tool	comments
1	 dry vacuum cleaning	<input type="checkbox"/>			V S Dust roller nozzle V Combi-nozzle	Monovac Twinvac	
2	 dusting damp mopping	<input type="checkbox"/>			S Masslinn 2000 Microsol cloth	Balit with pad sole	
cleaning without maintenance							
3	 wet mopping single step	<input type="checkbox"/>	Ecofloor	0.5 - 1% 1 - 2%	V S Microbrush-mop Microsmooth-mop Silkysmooth-mop	Wetbox system Wetcar / Drewell Socar / Drewell	
3	 spray mopping (wet mopping)	<input type="checkbox"/>	Ecofloor	0.5 - 1% 1 - 2%	V Micro nonwoven-1- Micro woven-1- Silkysmooth-1-	Variwet handle Balit with velcro Micro velcro sole	
3	 scrubber drying single step	<input type="checkbox"/>	Ecofloor Libero	0.5 - 1% 0.5 - 3%	V ● Pad red ● Melamine pad ● Microsol fibre pad	Duo- / Discomatic Sprinter / Drivematic	
cleaning with maintenance							
3	 wet mopping single step	<input type="checkbox"/>	Redur Remop	1 - 4% 1 - 2%	V S Microbrush-mop Microsmooth-mop Silkysmooth-mop	Wetbox system Socar / Drewell	
3	 scrubber drying single step	<input type="checkbox"/>	Redur Remop	1 - 4% 1 - 2%	V ● Pad red ● Melamine pad ● Microsol fibre pad	Duo- / Discomatic Sprinter / Drivematic	
3	 spray cleaning partial / full spray	<input type="checkbox"/>	Polyspray	100%	● Pad red P ● HS-Polish pad beige P ○ HS-Polish pad white	Monomatic DS Spray unit	after polishing 

* basic treatment / structure: B: coated / C: waxed / D: oiled / E: sealed / F: untreated / G: maintenance care product / H: Disinfection / P: polishing / S: structured / V: heavily soiled

important: Do not use magnetic tools and machines in the MRI and server room.

When spray cleaning, you should change your pad often.

General instructions for cleaning and care

no.36 Synthetic resin treated industrial flooring (conductive/antistatic)



interim cleaning

object _____

date _____



























address _____

customer _____

work process: select one work stage from each number

room classification _____

representative _____

↓	cleaning method	freq uenc	recommendations * chemical products	dosage	recommendations pad / brush / mop / cloth	recommendations machine / tool	comments
1	 dusting damp mopping	<input type="checkbox"/>			S Masslinn Microsol cloth	Balit with pad sole	
1	 dry vacuum cleaning	<input type="checkbox"/>			V S Dust roller nozzle V Combi-nozzle	Monovac Twinvac	if needed
cleaning without maintenance							
2	 wet mopping two-step	<input type="checkbox"/>	V Polex Antiwax forte classic	2 - 4% 2 - 5%	V S Microsmooth-mop Silkysmooth-mop	Socar / Drewell Wetcar / Drewell	 
2	 scrubber drying two-step	<input type="checkbox"/>	V Polex Antiwax forte classic	2 - 4% 2 - 5%	V  Pad red  Pad blue  Microsol fibre pad	Duo- / Discomatic Sprinter / Drivematic	 
3	 rinsing	<input type="checkbox"/>	Klares Wasser	100%	 Pad red  Microsol fibre pad	Monomatic LS Watertank Twinvac / Duovac	 
3	 rinsing	<input type="checkbox"/>	Klares Wasser	100%	 Pad red  Microsol fibre pad	Duo- / Discomatic Sprinter / Drivematic	 
cleaning with maintenance							
2	 spray cleaning full spray	<input type="checkbox"/>	Polyspray	100%	 Pad red P  HS-Polish pad beige P  HS-Polish pad white	Monomatic DS Spray unit	after polishing 

* basic treatment / structure: B: coated / C: waxed / D: oiled / E: sealed / F: untreated / G: maintenance care product / H: Disinfection / P: polishing / S: structured / V: heavily soiled

important: Do not use magnetic tools and machines in the MRI and server room.

When spray cleaning, you should change your pad often.

For initial cleaning after interim cleaning, see "initial cleaning".

General instructions for cleaning and care

no.36 Synthetic resin treated industrial flooring (conductive/antistatic)



basic cleaning

object _____

date _____



































address _____

customer _____

work process: select one work stage from each number

room classification _____

representative _____

cleaning method	freq uenc	recommendations * chemical products	dosage	recommendations pad / brush / mop / cloth	recommendations machine / tool	comments
1  dusting damp mopping	<input type="checkbox"/>			S Masslinn Microsol cloth	Balit with pad sole	
1  dry vacuum cleaning	<input type="checkbox"/>			V S Dust roller nozzle V Combi-nozzle	Monovac Twinvac	Do not use magnetic tools and machines in the
2  chewing gum removal	<input type="checkbox"/>	Karpfrost Karpotek	100% 100%			if needed 
3  damp vacuuming	<input type="checkbox"/>		0 100%	Microsol fibre pad for edges	Calorvac	 
cleaning without maintenance						
4  wet scrubbing and wet vacuuming	<input type="checkbox"/>	V Rewit 2000 B Antiwax forte classic B Relino	10 - 20% 30 - 50% 20 - 50%	B  Pad blue B  Pad green	Monomatic I / LS Watertank Twinvac / Duovac	  
4  scrubber drying two-step	<input type="checkbox"/>	V Rewit 2000 B Antiwax forte classic B Relino	10 - 20% 30 - 50% 20 - 50%	B  Pad blue B  Pad green B  Microsol fibre pad	Duo- / Discomatic Sprinter / Drivematic	large areas   
4  spray cleaning full spray	<input type="checkbox"/>	Antiwax forte classic	30 - 50%	B  Pad blue B  Pad green	Monomatic I / LS Spray unit	change pad often. 
5  rinsing	<input type="checkbox"/>		0 100%	 Pad blue B  Microsol fibre pad	Monomatic Watertank Twinvac / Duovac	 
5  rinsing	<input type="checkbox"/>		0 100%	 Pad blue B  Microsol fibre pad	Duo- / Discomatic Sprinter / Drivematic	large areas  

* basic treatment / structure: B: coated / C: waxed / D: oiled / E: sealed / F: untreated / G: maintenance care product / H: Disinfection / P: polishing / S: structured / V: heavily soiled

important: Do not use magnetic tools and machines in the MRI and server room.

For initial cleaning after basic cleaning, see "initial cleaning".

General instructions for cleaning and care

no.36 Synthetic resin treated industrial flooring (conductive/antistatic)



Information about the flooring




Wetrok AG cannot accept any liability for damages due to improper use.
For security information, see the safety data sheet at www.wetrok.com.
Wear the required personal protective equipment (PPE): e.g. protective gloves, safety goggles, work shoes.
Follow the information and remarks on the label, product data sheet and material safety data sheet.
The product data sheet describes the product and gives information about its application, storage. See www.wetrok.com.
The recommended colours of pad and brushes consist to the actual wWetrok product range.
Follow the special cleaning and care instructions of the floor manufacturer.
The cleaning and care instructions are recommendations and suggestions and apply to floorings in object quality.



Synthetic resin coverings are sensitive to organic solvents such as acetone.

Do not use solvent-based wax. Danger of slipping!
There must be no coating in the open air and in wet rooms. Danger of slipping!



Synthetic resin coverings consist of epoxy, polyurethane, polyester or acrylic resins, fillers and oxides.
Industrial coverings treated with synthetic resins are non-porous, pressure-resistant, mechanically loaded floor coverings with a mat or a gloss surface.
Industrial coverings treated with synthetic resins are cast or ground without joints or with expansion joints.



Remove loose dirt before every cleaning, damp mop smooth floors and vacuum structured floors.
Cleaning agents and surface treatments may alter the appearance and properties of a floor's surface.
Test on an inconspicuous spot to find which product is suitable for your requirements.
Test beforehand on an inconspicuous spot to see if the cleaning agent or surface treatment damages the floor.
Dirt-trapping zones, incl. dirt-trapping mats (Wetrok Gardamat) in the entrance, at least 7m long, greatly reduce the amount of dirt tracked into the building.

If you have any questions, please don't hesitate to contact us.
For training courses, contact the Wetrok Academy, tel. +41 (0)43 255 51 43 or academy@wetrok.ch.

Wetrok AG Steinackerstrasse 62, CH-8302 Kloten, telephone +41 (0)43 255 51 51, info@wetrok.ch, www.wetrok.com.